



PowerSport

SuperCrank® PART NUMBER	REPLACES	OPTIONAL BATTERY SUBSTITUTION	NOTES	Ah CAP. (10 Hr)	OVERALL DIMENSIONS (INCHES)		
					LENGTH	WIDTH	HEIGHT

EXIDE SUPERCRAK® XTRA BATTERIES 12-VOLT FACTORY ACTIVATED / FACTORY SEALED VRLA (AGM) - MAINTENANCE FREE - 6 Month Replacement

	Factory Activated	Spill Proof	Vibration Resistant	High Performance	Maintenance Free		
SC14FA	16-BS, YB16B-A2, YB16B-A12	--	Ⓞ	12	6	3-7/16	5-3/4
SC16CLBFA	Exact replacement for 16CL-B	--	Ⓞ	19	6-7/8	4	6-7/8
SC20HLFA	ETX20L or FA20L-BS, FA20HL-BS	--	Ⓞ	18	6-7/8	3-3/8	6-1/16
SC30LFA	Y1X30L	--	Ⓞ	28	6-1/2	5	6-7/8

EXIDE SUPERCRAK® SELECT BATTERIES - 12-VOLT PREMIUM VRLA (AGM) - MAINTENANCE FREE - 6 Month Replacement FRESH PACK KIT

			Vibration Resistant	High Performance	Maintenance Free		
4L-BS	--	--	Ⓞ	3	4-7/16	2-3/4	3-3/8
5L-BS	--	--	Ⓞ	4	4-7/16	2-3/4	4-1/8
7A-BS	--	--	Ⓞ	6	5-7/8	3-7/16	3-11/16
7L-BS	--	--	Ⓞ	6	4-7/16	2-3/4	5-1/8
9-BS	--	--	Ⓞ	8	5-7/8	3-7/16	4-3/16
12-BS	--	--	Ⓞ	10	5-7/8	3-7/16	5-3/16
14-BS	--	--	Ⓞ	12	6	3-7/16	5-3/4
14AH-BS	14A-A2, 14A-A1, 14-A2, 14-B2	--	Ⓞ	12	5-5/16	3-1/2	6-9/16
14AHL-BS	14L-A2, 14L-B2, 12N14-3A	--	Ⓞ	12	5-5/16	3-1/2	6-9/16
15L-BS	--	--	Ⓞ	13	6-7/8	3-7/16	5-1/8
16-BS	--	--	Ⓞ	14	6-15/16	4	6-1/8
16CL-B-BS	16CL-B	--	Ⓞ	19	6-7/8	4	6-7/8
16L-BS	--	--	ⓄⓄⓄ	14	6-15/16	4	6-1/8
18L-BS	50L-BS	--	Ⓞ	18	8-1/16	3-1/2	6-7/16
20-BS	--	20H-BS	Ⓞ	18	6-7/8	3-3/8	6-1/16
20CH-BS	--	--	Ⓞ	18	6	3-7/16	6-3/8
20H-BS	--	--	Ⓞ	18	6-7/8	3-3/8	6-1/16
20L-BS	--	20HL-BS	Ⓞ	18	6-7/8	3-3/8	6-1/16
20HL-BS	--	--	Ⓞ	18	6-7/8	3-3/8	6-1/16
24HL-BS	18L-BS, 50-N18L-A2/3	--	Ⓞ	21	8-1/8	3-7/16	6-3/8

EXIDE SUPERCRAK® -12-VOLT HIGH PERFORMANCE FLOODED -- 6 Month Replacement FRESH PACK KIT (battery, acid, hardware, instructions)

				High Performance	Maintenance Free		
4L-B	--	--	Ⓞ	4	4-3/4	2-7/8	3-11/16
7C-A	12N7C-3D	--	Ⓞ	8	5-1/8	3-9/16	4-1/2
9A-A	--	--	Ⓞ	9	5-3/8	3	6-1/16
9-B	--	--	Ⓞ	9	5-3/8	3	5-1/2
9L-B	--	--	Ⓞ	9	5-3/8	3	5-1/2
10A-A2	--	--	Ⓞ	11	5-3/8	3-9/16	6-1/8
10L-A2	12N10-3A, 12N10-3A1, 12N10-3A2	--	ⓄⓄ	11	5-3/8	3-9/16	5-3/4
10L-B	12N10-3B	--	ⓄⓄ	11	5-3/8	3-9/16	5-3/4
12A-A	--	--	Ⓞ	12	5-5/16	3-3/16	6-5/16
12AL-A	--	--	Ⓞ	12	5-5/16	3-3/16	6-5/16
12C-A	--	--	Ⓞ	12	5-5/16	3-3/16	6-7/8
14-A2	--	--	Ⓞ	14	5-5/16	3-9/16	6-9/16
14A-A2	14A-A1	--	Ⓞ	14	5-5/16	3-9/16	6-15/16
14L-A2	12N14-3A	--	Ⓞ	14	5-5/16	3-9/16	6-9/16
16A-AB	--	--	Ⓞ	16	5-15/16	3-9/16	7-3/16
16AL-A2	--	--	Ⓞ	16	8-1/16	2-7/8	6-7/16
16-B	--	16L-BS	ⓄⓄ	19	6-15/16	4	6-1/8
16CL-B	--	16CL-B-BS	ⓄⓄ	19	6-7/8	4	6-7/8
16L-B	12N16-3B	--	ⓄⓄⓄ	19	6-15/16	4	6-1/8
18L-A	--	20-BS	ⓄⓄ	18	7-3/16	3-5/8	6-7/16
50-N18L-A2	--	18L-BS	ⓄⓄ	20	8-1/8	3-9/16	6-7/16

EXIDE SUPERCRAK® - 6-VOLT CONVENTIONAL FLOODED -- 6 Month Replacement FRESH PACK KIT (battery, acid, hardware, instructions)

				Maintenance Free			
6N5.5-1D	--	--	Ⓞ	5.5	3-9/16	2-3/4	3-7/8
6N6-3B	--	--	Ⓞ	6	3-7/8	2-1/4	4-3/8

EXIDE SUPERCRAK® -12-VOLT CONVENTIONAL FLOODED -- 6 Month Replacement FRESH PACK KIT (battery, acid, hardware, instructions)

12N5-4B	--	--	Ⓞ	5	4-3/4	2-3/8	5-3/16
12N5.5A-3B	--	--	Ⓞ	5.5	4-1/16	3-9/16	4-1/2
12N7-3B	--	7L-B	Ⓞ	7	5-3/8	3	5-1/4
12N7-4A	--	7-A	Ⓞ	7	5-3/8	3	5-1/4
12N9-4B-1	--	9-B, 12A-A	Ⓞ	9	5-3/8	3	5-1/2
12N12A-4A-1	--	12A-A	Ⓞ	12	5-5/16	3-3/16	6-5/16
12N14-3A	--	14L-A2	Ⓞ	14	5-5/16	3-9/16	6-9/16
HD-12	--	--	Ⓞ	28	8-1/16	5-1/8	6-1/2

NOTES:

- (1) Check cable-to-terminal connection design and battery dimensions for proper fitment.
- (2) Dry charge battery - requires ACID 32 OZ Acid Bottle for activation.
- (3) SEALED VRLA (AGM) - battery and acid included in carton.
- (4) FP - Fresh Pack - Battery and acid included in carton.
- (5) Check fit for potential height adaptor use.
- (6) SEALED - VRLA - AGM Battery, factory filled, charged and activated.
- (8) UNIV. contains all the wire lead connectors to fit all 6-Volt batteries of that capacity level.
- (7) Hold-down modification may be required.